


Exploded View:



Note:

If the frame is used for a Vibraphone the long cross piece with the hole for a pedal assembly should be on the bottom with the hole facing up.

Included Hardware:

4x Short bolts that connect the Short Cross pieces to the end tops

4x Long bolts that connect the Short cross pieces to the end bottoms

12x medium bolts that attach the long and short cross pieces and the top and bottom ends

16x Caster bolts